

Spring Street Analytical

350 Spring Street  
Klamath Falls, OR 97601  
Maurene Ehlers, Lab Director  
(541)882-6286

# Invoice

Date	Invoice #
6/21/2016	30182


Received by  
**JUN 23 2016**  
Facilities

Bill To
Oregon Institute of Technology Attn: Facilities 3201 Campus Drive Klamath Falls, OR 97601-8801

P.O. No.	Terms	Project
June	Net 30	

Quantity	Description	Rate	Amount
20	Lead / Copper 5 or more samples submitted at same time/each	45.00	900.00
1	Large Cooler Shipping Expense	35.00	35.00
		<b>Total</b>	<b>\$935.00</b>

E-mail
waterlab@qwestoffice.net



# NEILSON RESEARCH CORPORATION

*Environmental Testing Laboratory*

6/20/2016

Maurene Ehlers  
Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

TEL: (541) 882-6286

FAX: (541) 882-9561

RE: OIT-Lead and Copper Study

Order No.: 1606580

Dear Maurene Ehlers:

Neilson Research Corporation received 20 sample(s) on 6/14/2016 for the analyses presented in the following report.

The results relate only to the parameters tested or to the sample as received by the laboratory. This report shall not be reproduced except in full, without the written approval of Neilson Research Corporation. If you have any questions regarding these test results, please feel free to call.

Sincerely,  
Neilson Research Corporation

Alec C Smith  
Project Manager

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

**CLIENT:** Spring Street Analytical  
**Project:** OIT-Lead and Copper Study  
**Lab Order:** 1606580

**Date:** 20-Jun-16

## CASE NARRATIVE

The analyses were performed according to the guidelines in the Neilson Research Corporation Quality Assurance Program. This report contains analytical results for the sample(s) as received by the laboratory.

Neilson Research Corporation certifies that this report is in compliance with the requirements of NELAP. No unusual difficulties were experienced during analysis of this batch except as noted below or qualified with data flags on the reports.

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-01A  
Collection Date: 6/14/2016 5:58:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

### OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 07345  
Sample Location: Cornett Hall Wash Sta S-119  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0533		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000328		0.0001	mg/L	0.015	6/15/2016	OML

#### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

1



# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-02A  
Collection Date: 6/14/2016 6:04:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 07336  
Sample Location: Dow Hall Kitchen 231  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0310		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000261		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

ORELAP 100016  
EPA OR00028

## Analysis Report

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-03A  
Collection Date: 6/14/2016 6:14:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 07340  
Sample Location: LRC Break Room 227  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0639		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000133		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-04A  
Collection Date: 6/14/2016 6:10:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

### OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 07359  
Sample Location: PE Training Rm 207C  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0727		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000906		0.0001	mg/L	0.015	6/15/2016	OML

#### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

ORELAP 100016  
EPA OR00028

## Analysis Report

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-05A  
Collection Date: 6/14/2016 6:19:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 12578  
Sample Location: Stadium VIP Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.111		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00183		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-06A  
Collection Date: 6/14/2016 4:49:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

### OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 05074  
Sample Location: Boivin Hall Break Room 168  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0549		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00375		0.0001	mg/L	0.015	6/15/2016	OML

#### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100018  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-07A  
Collection Date: 6/14/2016 5:16:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

### OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20408  
Sample Location: CU Lower Mens Room  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0713		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00116		0.0001	mg/L	0.015	6/15/2016	OML

#### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

ORELAP 100016  
EPA OR00028

## Analysis Report

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-08A  
Collection Date: 6/14/2016 4:37:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20414  
Sample Location: Purvine Hall Duffy Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0180		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000492		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical

350 Spring Street

Klamath Falls, OR 97601

Lab Order: 1606580

NRC Sample ID: 1606580-09A

Collection Date: 6/14/2016 5:35:00 AM

Received Date: 6/14/2016 4:00:00 PM

Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997

Source ID: DIST-A

Sample Comp:

Client Sample ID: Bottle # 20418

Sample Location: CU Sodexo Kitchen Janitor

Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0589		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00437		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit



# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical

350 Spring Street

Klamath Falls, OR 97601

Lab Order: 1606580

NRC Sample ID: 1606580-10A

Collection Date: 6/14/2016 5:49:00 AM

Received Date: 6/14/2016 4:00:00 PM

Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997

Source ID: DIST-A

Sample Comp:

Client Sample ID: Bottle # 20415

Sample Location: Facility Bldg Shop Sink 112

Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0254		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000379		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-11A  
Collection Date: 6/14/2016 5:39:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20410  
Sample Location: CU Subway Back Rm Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0438		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000555		0.0001	mg/L	0.015	6/15/2016	OML

Notes: ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-12A  
Collection Date: 6/14/2016 5:55:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20417  
Sample Location: Cornett Hall Janitor 115-E  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0960		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00139		0.0001	mg/L	0.015	6/15/2016	OML

Notes: ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA QR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-13A  
Collection Date: 6/14/2016 5:16:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20411  
Sample Location: Vlg Red Bldg 1st Flr Janitor  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0187		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000696		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-14A  
Collection Date: 6/14/2016 4:56:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 03886  
Sample Location: Owens Hall Rm 125A Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0558		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000209		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-15A  
Collection Date: 6/14/2016 5:43:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20413  
Sample Location: Snell Hall 1st Flr Janitor Clst  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.165		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.00159		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-16A  
Collection Date: 6/14/2016 5:02:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 20416  
Sample Location: Res Hall Laundry Rm Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0447		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000162		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL

N.L. = No Limit

MDL = Method Detection Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-17A  
Collection Date: 6/14/2016 5:19:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 03891  
Sample Location: Vlg Blue Bldg 1st Flr Janitor  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0209		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000194		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit



# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100018  
EPA QR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-18A  
Collection Date: 6/14/2016 5:13:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 03892  
Sample Location: Vlg Yellow Bldg 1st Flr Janitor  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0208		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000382		0.0001	mg/L	0.015	6/15/2016	OML

Notes: ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-19A  
Collection Date: 6/14/2016 4:45:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

### OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 04100  
Sample Location: Semons Hall Brk Rm Sink 230  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0529		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000696		0.0001	mg/L	0.015	6/15/2016	OML

#### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

## Analysis Report

ORELAP 100016  
EPA OR00028

Spring Street Analytical  
350 Spring Street  
Klamath Falls, OR 97601

Lab Order: 1606580  
NRC Sample ID: 1606580-20A  
Collection Date: 6/14/2016 5:04:00 AM  
Received Date: 6/14/2016 4:00:00 PM  
Reported Date: 6/20/2016 12:02:34 PM

## OIT-Lead and Copper Study

PWS ID#: 41-93997  
Source ID: DIST-A  
Sample Comp:

Client Sample ID: Bottle # 05099  
Sample Location: Res Hall Snack Bar Sink  
Collectors Name: Jeff Olson

## ANALYTICAL RESULTS

Analyses	Code	Method	NELAP Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0201		0.0005	mg/L	1.3	6/16/2016	OML
Lead	1030	EPA 200.8	A	0.000627		0.0001	mg/L	0.015	6/15/2016	OML

### Notes:

ND - Not Detected at the MRL  
MDL = Method Detection Limit

N.L. = No Limit

# Neilson Research Corporation

Date: 20-Jun-16

CLIENT: Spring Street Analytical  
Work Order: 1606580

Project: OIT-Lead and Copper Study

## ANALYTICAL QC SUMMARY REPORT

TestCode: ICPMS\_200.8\_PWS

Sample ID: MB-35449	SampType: MBLK	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87874
Client ID: ZZZZZ	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/15/2016	SeqNo: 1310818
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC LowLimit HighLimit RPD Ref Val %RPD RPDLimit Qual

Copper ND 0.000500  
Lead ND 0.000100

Sample ID: MB-35449	SampType: MBLK	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87876
Client ID: ZZZZZ	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/16/2016	SeqNo: 1310862
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC LowLimit HighLimit RPD Ref Val %RPD RPDLimit Qual

Copper ND 0.000500  
Lead ND 0.000100

Sample ID: LCS-35449	SampType: LCS	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87874
Client ID: ZZZZZ	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/15/2016	SeqNo: 1310819
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC LowLimit HighLimit RPD Ref Val %RPD RPDLimit Qual

Copper 0.09189 0.000500 0.1 0 91.9 85 115  
Lead 0.09786 0.000100 0.1 0 97.9 85 115

Sample ID: LCS-35449	SampType: LCS	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87876
Client ID: ZZZZZ	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/16/2016	SeqNo: 1310863
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC LowLimit HighLimit RPD Ref Val %RPD RPDLimit Qual

Copper 0.09390 0.000500 0.1 0 93.9 85 115  
Lead 0.09941 0.000100 0.1 0 99.4 85 115

Sample ID: 1606580-20AMS	SampType: MS	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87874
Client ID: Bottle # 05099	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/15/2016	SeqNo: 1310842
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC LowLimit HighLimit RPD Ref Val %RPD RPDLimit Qual

Qualifiers: E Value above quantitation range  
ND Not Detected at the Minimum Reporting Limit  
H Holding times for preparation or analysis exceeded  
R RPD outside accepted recovery limits  
J Analyte detected below quantitation limits  
S Spike Recovery outside accepted recovery limits

# Neilson Research Corporation

Date: 20-Jun-16

CLIENT: Spring Street Analytical  
 Work Order: 1606580  
 Project: OIT-Lead and Copper Study

## ANALYTICAL QC SUMMARY REPORT

TestCode: ICPMS\_200.8\_PWS

Sample ID: 1606580-20AMS		SampType: MS		TestCode: ICPMS_200.8		Units: mg/L		Prep Date: 6/15/2016		RunNo: 87874	
Client ID: Bottle # 05099		Batch ID: 35449		TestNo: EPA 200.8		(EPA 200.8)		Analysis Date: 6/15/2016		SeqNo: 1310842	
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Lead	0.09326	0.000100	0.1	0.0006269	92.6	70	130				

Sample ID: 1606580-20AMS		SampType: MS		TestCode: ICPMS_200.8		Units: mg/L		Prep Date: 6/15/2016		RunNo: 87876	
Client ID: Bottle # 05099		Batch ID: 35449		TestNo: EPA 200.8		(EPA 200.8)		Analysis Date: 6/16/2016		SeqNo: 1310886	
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Copper	0.1139	0.000500	0.1	0.02006	93.8	70	130				

Sample ID: 1606580-20AMSD	SampType: MSD	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 6/15/2016	RunNo: 87874						
Client ID: Bottle # 05099	Batch ID: 35449	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 6/15/2016	SeqNo: 1310843						
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Lead	0.09673	0.000100	0.1	0.0006269	96.1	70	130	0.09326	3.65	20	

Sample ID: 1606580-20AMSD		SampType: MSD		TestCode: ICPMS_200.8		Units: mg/L		Prep Date: 6/15/2016		RunNo: 87876	
Client ID: Bottle # 05099		Batch ID: 35449		TestNo: EPA 200.8		(EPA 200.8)		Analysis Date: 6/16/2016		SeqNo: 1310887	
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Copper	0.1119	0.000500	0.1	0.02006	91.8	70	130	0.1139	1.77	20	

Qualifiers: E Value above quantitation range  
 ND Not Detected at the Minimum Reporting Limit  
 H Holding times for preparation or analysis exceeded  
 R RPD outside accepted recovery limits  
 J Analyte detected below quantitation limits  
 S Spike Recovery outside accepted recovery limits

Lab Sample ID  
Date Received  
Time Received  
Received By

1606580-CIA  
6/14/16  
16:00  
[Signature]

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 1802 (am/pm) Date 06/13/2016  
Sample was collected: Time 0558 (am/pm) Date 06/14/2016  
Name of Water System OIT PWS ID 41- 93997  
Sample Collected by Jeff Olson Bottle # 07345  
Address 3201 Campus Dr Klamath Falls OR 97601 Space # \_\_\_\_\_  
Faucet Location CONNERT HALL - EMERGENCY WASH STATION (S-119)  
Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16



Lab Sample ID 16065230-024Date Received 6/14/16Time Received 16:00Received By DN

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used:

Time 1856 (am/pm) Date 06/13/2016

Sample was collected:

Time 0604 (am/pm) Date 06/14/2016Name of Water System OITPWS ID # 93997Sample Collected by Jeff OlsonBottle # 07336Address 3201 Campus Dr. Klamath Falls OR 97601

Space # \_\_\_\_\_

Faucet Location DOW HALL KITCHEN (231/DOWN)

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature]Date 6/14/16

Lab Sample ID 11006550-024Date Received 6/14/16Time Received 16:00Received By JD

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 18:00 (am/pm) Date 06/13/2016

Sample was collected: Time 06:14 (am/pm) Date 06/14/2016

Name of Water System OIT PWS ID 41- 93997

Sample Collected by Jeff Olson Bottle # 07340

Address 3201 Campus Drive Klamath Falls OR 97601 Space # \_\_\_\_\_

Faucet Location L.R.C. - BATH ROOM (2nd)

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16



Lab Sample ID

Date Received

Time Received

Received By

1606550-047  
6/14/16  
16:00  
D

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.


If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 1747 (am/pm) Date 06/13/2016  
 Sample was collected: Time 0610 (am/pm) Date 06/14/2016  
 Name of Water System OIT PWS ID 41- 93997  
 Sample Collected by Jeff Olson Bottle # 07359  
 Address 3201 Campus Dr Klamath Falls OR 97601 Space # \_\_\_\_\_  
 Faucet Location PE, TRAINING RM (207C)  
 Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16



# NEILSON RESEARCH CORPORATION

LAB NRC Sample Number: 1606550-00A  
Received By: (Signature)

Date Received: 6/14/16  
Time Received: 10:00 am/pm

## Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.
2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. **Do not** intentionally flush the water line before the start of the 6 hour period.
3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. **Do not** remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked "1000-mL" and turn off the water.
4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.
6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.
7. Results from this monitoring effort and information about lead will be provided to you as soon as practical but no later than 30 days after the system learns of the tap monitoring results. However, if excessive lead and/or copper levels are found, immediate notification will be provided (usually 1-2 working days after the system learns of the tap monitoring results).

Call \_\_\_\_\_ at \_\_\_\_\_ if you have any questions.

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 17:51 am/pm Date 06/13/2016  
Sample was collected: Time 06:19 am/pm Date 06/14/2016  
Name of Water System: CIT PWS ID 41- 93997  
Sample Collected by: Jeff Olson Bottle # 12578  
Address: 3201 Campus Dr. Klamath Falls OR 97601 Space # \_\_\_\_\_  
Faucet Location: (e.g. Kitchen Faucet) STADIUM VIP SINK

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature (Signature) Date 6/14/16

Lab Sample ID

11606580-06A

Date Received

6/14/16

Time Received

16:00

Received By

DN

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used:

Time 1730 (am/pm) Date 06/13/2016

Sample was collected:

Time 0949 (am/pm) Date 06/14/2016

Name of Water System

OIT

PWS ID 41-

93997

Sample Collected by

Jeff Olson

Bottle #

DS074

Address

3201 Campus Dr Klamath Falls OR 97601

Space #

Faucet Location

BOWEN HALL, FACULTY BREAK ROOM (RM 118) HAND SINK

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature

Jeff Olson

Date

6/14/16

Lab Sample ID 16065282-0711  
 Date Received 6/14/16  
 Time Received 11:50  
 Received By DS

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>4:17</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0516</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System	<u>OET</u> PWS ID 41- <u>93997</u>
Sample Collected by	<u>Jeff Olson</u> Bottle # _____
Address	<u>3201 Campus Dr Klamath Falls, OR 97601</u>
Faucet Location	<u>ELL LOWER FLOOR MEN'S RESTROOM</u> <u>LEFT SINK</u>
Note any plumbing repairs or replacements made since last sampling event: _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature	<u>[Signature]</u> Date <u>6/14/16</u>

**STERILE BOTTLE # 20408**  
**SPRING STREET ANALYTICAL**  
350 SPRING STREET • KLAMATH FALLS, OR 97601  
 (541) 882-6286 • FAX (541) 882-9561  
**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**



Lab Sample ID 1006700-047  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DD

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.


Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1727</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0437</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OIT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle # _____
Address <u>3201 Campus Dr Klamath Falls OR 97601</u>	
Faucet Location <u>PURVIEW HALL, DUFFY'S HAND SINK</u>	
Note any plumbing repairs or replacements made since last sampling event _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>



Sample ID 10065007011  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DS

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and the water department.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 1813 (am/pm) Date 06/13/2016

Sample was collected: Time 0535 (am/pm) Date 06/14/2016

Name of Water System OIT PWS ID 41- 93997

Sample Collected by Jeff Olson Bottl

Address 3201 Campus Dr Klamath Falls OR 97601

Faucet Location GL SODIXO KITCHEN JANITOR

Note any plumbing repairs or replacements made since last sampling eve

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16



STERILE BOTTLE # **20418**

**SPRING STREET ANALYTICAL**

350 SPRING STREET • KLAMATH FALLS, OR 97601  
 (541) 882-6286 • FAX (541) 882-9561

**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**

Lab Sample ID

Date Received

Time Received

Received By

11206588-1014  
6/14/16  
16:00  
JPO

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tighten cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 1756 (am/pm) Date 06/13/2016

Sample was collected: Time 0549 (am/pm) Date 06/14/2016

Name of Water System OIT PWS ID 41- 93997

Sample Collected by Jeff Olson Bottle

Address 3201 Campus Dr Klamath Falls OR 97601

Faucet Location FRUITIERES BLDG, ELECTRICAL

Note any plumbing repairs or replacements made since last sampling event SHUT SHUT (11/2)



STERILE BOTTLE # 20415

SPRING STREET ANALYTICAL

350 SPRING STREET • KLAMATH FALLS, OR 97601  
(541) 882-6286 • FAX (541) 882-9561

CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16



Lab Sample ID 160655011A  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DJ

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1820 (am/pm)</u> Date <u>06/13/2016</u>
Sample was collected:	Time <u>0539 (am/pm)</u> Date <u>06/14/2016</u>
Name of Water System <u>OET</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle # _____
Address <u>3201 Campus Dr Klamath Falls, OR 97601</u>	
Faucet Location <u>CK, SINK, PARK, RM FALL RT SINK</u>	
Note any plumbing repairs or replacements made since last sampling event: _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>

**STERILE BOTTLE # 20410**  
**SPRING STREET ANALYTICAL**  
350 SPRING STREET • KLAMATH FALLS, OR 97601  
 (541) 882-6286 • FAX (541) 882-9561  
**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**



Date Received 6/14/16  
 Time Received 16:00  
 Received By (Signature)

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
  2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
  3. Tightly cap the sample bottle. Please carefully complete this form.
- IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
- Place the sample with form attached outside of the residence in the location of the delivery for pick up.
- Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1714</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0555</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OIT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle _____
Address <u>3201 Campus Dr Klamath Falls OR 97601</u>	
Faucet Location <u>Garrett Hall Janitor (115E)</u>	
Note any plumbing repairs or replacements made since last sampling event _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>(Signature)</u>	Date <u>6/14/16</u>

**STERILE BOTTLE # 20417**

**SPRING STREET ANALYTICAL**

350 SPRING STREET • KLAMATH FALLS, OR 97601  
(541) 882-6286 • FAX (541) 882-9561

**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**

Sample ID 160658-134  
 Date Received 6/14/16  
 Time Received 10:00  
 Received By DD

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>12:47</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>05:16</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OLT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle # _____
Address <u>3201 Campus Dr. Klamath Falls, OR 97601</u>	
Faucet Location <u>VILLAGE, RED BLDG, JANITOR C-500</u>	
Note any plumbing repairs or replacements made since last sampling event: _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>



STERILE BOTTLE # **20411**

**SPRING STREET ANALYTICAL**

350 SPRING STREET • KLAMATH FALLS, OR 97601  
(541) 882-6286 • FAX (541) 882-9561

**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**

Lab Sample ID 1606580-1412  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DJ

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1717</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0456</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OIT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Chen</u>	Bottle # <u>03886</u>
Address <u>3201 Campus Dr Klamath Falls OR 97601</u> Space # _____	
Faucet Location <u>OWENS HALL, FACULTY BREAK RM (125A) HAND SINK</u>	
Note any plumbing repairs or replacements made since last sampling event:	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>

Lab Sample ID

Date Received

Time Received

Received By

160658-15H  
6/14/16  
16:00  
D11

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used:

Time 1739 (am/pm) Date 06/13/2016

Sample was collected:

Time 0543 (am/pm) Date 06/14/2016Name of Water System OITPWS ID 41- 93997Sample Collected by Jeff Olson

Bottle #

STERILE BOTTLE # 20413Address 3201 Campus Dr. Klamath Falls OR 97601Faucet Location SMELL HALL, 1ST FLOOR JANITORNote any plumbing repairs or replacements made since last sampling event: CLOSET

SPRING STREET ANALYTICAL

350 SPRING STREET • KLAMATH FALLS, OR 97601  
(541) 882-6286 • FAX (541) 882-9561

CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature Jeff OlsonDate 6/14/16

Revision 0

Effective Date: 02/01/12



Lab Sample ID 16-1652-16M  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DA

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1833</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0502</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OFT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	B
Address <u>3201 Campus Dr Klamath Falls OR 97601</u>	
Faucet Location <u>RESIDENCE HALL LAUNDRY RM SINK</u>	
Note any plumbing repairs or replacements made since last sampling _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>

**STERILE BOTTLE # 20416**  
**SPRING STREET ANALYTICAL**  
350 SPRING STREET • KLAMATH FALLS, OR 97601  
 (541) 882-6286 • FAX (541) 882-9561  
**CONTAINS SODIUM THIOSULFATE. DO NOT RINSE.**

Lab Sample ID 11606530174  
 Date Received 6/14/16  
 Time Received 16:00  
 Received By DT

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_.

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1830</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0519</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OIT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle # <u>03891</u>
Address <u>3201 Campus Dr. Klamath Falls OR 97601</u> Space # _____	
Faucet Location <u>VILLAGE, BLUE BLDG, 1ST FLR JANITOR CLOSE</u>	
Note any plumbing repairs or replacements made since last sampling event:	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>

Lab Sample ID 11606580-187  
Date Received 6/14/16  
Time Received 10:00  
Received By DN

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and water utilities.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used:

Time 12:00 (am/pm) Date 06/13/2016

Sample was collected:

Time 0513 (am/pm) Date 06/14/2016

Name of Water System OJT

PWS ID 41- 93997

Sample Collected by Jeff Olson

Bottle # 03892

Address 3201 Campus Dr Klamath Falls OR 97601 Space # \_\_\_\_\_

Faucet Location VILLAGE, YELLOW BLDG, JANITOR 1ST FLOOR

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature]

Date 6/14/16

Lab Sample ID 1606580-914  
 Date Received 6/14/16  
 Time Received 10:00  
 Received By DT

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fixtures from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_.

TO BE COMPLETED BY RESIDENT	
Water was last used:	Time <u>1722</u> (am/pm) Date <u>06/13/2016</u>
Sample was collected:	Time <u>0415</u> (am/pm) Date <u>06/14/2016</u>
Name of Water System <u>OLT</u>	PWS ID 41- <u>93997</u>
Sample Collected by <u>Jeff Olson</u>	Bottle # <u>04100</u>
Address <u>3201 Campus Dr. Klamath Falls OR 97601</u> Space # _____	
Faucet Location <u>SEMONS HALL, FACULTY BREAK RM SINK (RM 230)</u>	
Note any plumbing repairs or replacements made since last sampling event: _____	
I have read the above directions and have taken a tap sample in accordance with these directions.	
Signature <u>[Signature]</u>	Date <u>6/14/16</u>



Lab Sample ID

Date Received

Time Received

Received By

11606531-277

6/14/16

16:00

DN

## Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or faucets from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call: \_\_\_\_\_

### TO BE COMPLETED BY RESIDENT

Water was last used: Time 1837 (am/pm) Date 06/13/2016

Sample was collected: Time 0504 (am/pm) Date 06/14/2016

Name of Water System OIT PWS ID 41- 93997

Sample Collected by Jeff Olson Bottle # 05099

Address 3201 Campus Dr Klamath Falls OR 97601 Space # \_\_\_\_\_

Faucet Location RESIDENCE HALL, SINK BAR, BACK RM SINK

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 6/14/16